

## PNÖMATİK OTOMATİK HORTUM FİTINGSLERİ PNEUMATIC PUSH IN TUBE FITTINGS

### OTOMATİK PERDE GEÇİŞ DİRSEK BAĞLANTI PUSH IN BULK HEAD ELBOW FITTING

#### MODEL PH-MLP



SİPARİŞ KODU ORDER CODE	ØD HORTUM DIŞ ÇAPI HOSE EXTERNAL DIA. (MM)
PH-MLP	4
PH-MLP	6
PH-MLP	8
PH-MLP	10
PH-MLP	12

### OTOMATİK ORANTILI NİPEL BAĞLANTILAR PUSH IN STRAIGHT REDUCING UNION FITTINGS

#### MODEL PN-GP



SİPARİŞ KODU ORDER CODE	HORTUM DIŞ ÇAPI HOSE EXTERNAL DIA. (MM) ØD1	HORTUM DIŞ ÇAPI HOSE EXTERNAL DIA. (MM) ØD2
PN-GP	6	4
PN-GP	8	6
PN-GP	10	8
PN-GP	12	10
PN-GP	16	12

### OTOMATİK DÜŞÜRÜCÜ REDÜKSİYON STRAIGHT PLUG IN REDUCER FITTING

#### MODEL PN-JGP



SİPARİŞ KODU ORDER CODE	HORTUM DIŞ ÇAPI HOSE EXTERNAL DIA. ØD1	BORU DIŞ ÇAPI TUBE EXTERNAL DIA. ØD2(MM)
PN-JPG	3	4
PN-JPG	4	5
PN-JPG	4	6
PN-JPG	5	6
PN-JPG	4	8
PN-JPG	6	8
PN-JPG	4	10
PN-JPG	6	10
PN-JPG	8	10
PN-JPG	6	12
PN-JPG	8	12
PN-JPG	10	12

### OTOMATİK NİPEL BAĞLANTILAR PUSH IN STRAIGHT UNION FITTINGS STRAIGHT

#### MODEL PN-UP



SİPARİŞ KODU ORDER CODE	HORTUM DIŞ ÇAPI HOSE EXTERNAL DIA. (MM) ØD1	HORTUM DIŞ ÇAPI HOSE EXTERNAL DIA. (MM) ØD2
PN-UP	4	4
PN-UP	6	6
PN-UP	8	8
PN-UP	10	10
PN-UP	12	12
PN-UP	14	14
PN-UP	16	16

### DIŞLİ BORU BAĞLANTI HOSE ADAPTOR

#### MODEL PH-JCP



SİPARİŞ KODU ORDER CODE	R1	ØD HORTUM DIŞ ÇAPI HOSE EXTERNAL DIA. (MM)
PH-JCP	M5	4
PH-JCP	1/8"	4
PH-JCP	1/4"	4
PH-JCP	M5	6
PH-JCP	1/8"	6
PH-JCP	1/4"	6
PH-JCP	1/8"	8
PH-JCP	1/4"	8
PH-JCP	1/4"	10
PH-JCP	3/8"	10
PH-JCP	1/2"	10
PH-JCP	1/4"	12
PH-JCP	3/8"	12
PH-JCP	1/2"	12
PH-JCP	1/2"	16

### OTOMATİK DİRSEK ELBOW PLUG IN REDUCER FITTING

#### MODEL PN-JLP



SİPARİŞ KODU ORDER CODE	HORTUM DIŞ ÇAPI HOSE EXTERNAL DIA. / ØD1	BORU DIŞ ÇAPI TUBE EXTERNAL DIA. ØD2(MM)
PN-JLP	4	4
PN-JLP	6	6
PN-JLP	8	8
PN-JLP	10	10
PN-JLP	12	12
PN-JLP	16	16